




VTech CS6114 Base Motherboard Replacement

A step-by-step guide to replace the motherboard of the base of a VTech CS6114 cordless phone.

Written By: Sheckeem Daley



INTRODUCTION


The base's motherboard is attached via wires, to the bracket of the charging contact points.



TOOLS:


- [Phillips #0 Screwdriver](#) (1)
 - [Heavy-Duty Spudger](#) (1)
-

Step 1 — Base Motherboard



- Unscrew the two 10.0mm Philips #0 screws located on the bottom and the back of the base. There should be two screws on the bottom of the base and a single screw on the back.

Step 2




- Facing the bottom side of the base, run the black spudger along the crevice to one side, and then to the other.
- With a gentle application of force, the two parts of the base's body should separate.

Step 3



- Hold the anterior part of the base's body, with the side which shows only the exterior, facing the palm.
- Unscrew the 10.0mm Philips #0 round head screw, located on the black bracket which holds the charger contact points.
- The black bracket should pop off.

Step 4



- Gently pull up on motherboard, in order to separate it from the base.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-26 10:51:39 AM.